


COMPONENTS

<p>Handle EKONOMIK</p> <p>textile door stop (inserted) 4,8 mm x 4 mm</p>	<p>Top track EKONOMIK</p>	<p>Bottom track EKONOMIK</p>	<p>Horizontal profile Ekonomik</p>	<p>Screws</p> <ul style="list-style-type: none"> Toothed washer 3 x 6 Fastening of carriages Self-tapping screw with washer head 2,9 x 6,5 Fastening of carriages Countersunk screw 3 x 16 Fastening of tracks Dome head screw 3x10 Fastening of handle (with chipboard filling)
<p>Bottom carriage EKONOMIK</p>	<p>Top carriage EKONOMIK</p>	<p>Covering strip</p>		



Dimensions of opening




ATTENTION!
Mirror (4 mm) must be used with a safety backing film.



door filling - 10 mm board, 4 mm mirror

door height	- h	$h = H - 32 \text{ mm}$
board height	- hb	$hb = h - 2 \text{ mm}$
door width	- w	$w = (W - 3 \text{ mm} + Z) : N$
board width	- wb	$wb = w - 2 \text{ mm}$
horizontal profile length	- L	$L = w - 48 \text{ mm}$
mirror height	- hm	$hm = hb - 4 \text{ mm}$
mirror width	- wm	$wm = wb - 4 \text{ mm}$

number of doors	- N	2	3
total overlap	- Z	25 mm	50 mm




visual design - 4 wings	
	$w = (W + 72) : 4$
	$w = (W : 2 + 22) : 2$




Installation method for fitting 10 mm board (diag. A) and 4 mm mirror or glass (diag. B)


- with handle Ekonomik



- top carriage



- bottom carriage



ATTENTION!

Remove protective film from aluminium elements (handles, tracks, connectors, etc.) prior to cutting them to the desired size. Film removal will reveal quality issues (eg. scratches)